
RFC - RF Cylinder Thermostat

Page 1 of 1

Installation Instructions



- If this device is used in a way not specified by the maufacturer, it's safety may be impaired.
- Ensure that this wireless enabled thermostat is installed 1 metre from any metallic object, television, radio or wireless internet transmitter.


This thermostat can be mounted in the following ways:


- To a recessed conduit box
- To a surface mounted box
- Directly mounted on wall





Important: Keep this document



















technical@ephcontrols.com www.ephcontrols.com